

# ICON Rafter Roll

## Technical Data Sheet

### PRODUCT



### INSTALLATION

- Before the underlay is installed, unroll the ventilator along the rafters the full length of the eaves. This should be carried out both sides of the building to create a cross flow.
- The roll should be positioned centrally above the wall plate. This is the narrowest part of the roof where the insulation is most likely to restrict airflow.
- Push the corrugations down over the top of the rafters and secure using clout nails or staples.
- For deeper insulation it may be necessary to use either the 600 or 800mm roll size
- Lay roofing felt over the rafter roll and batten as necessary.



### USES

- For roof eaves ventilation on pitched roofs
- On standard pitched roofs where the pitch is 15° or more and the roof void is an attic or loft space
- On roofs with rafter spacings of between 400mm and 600mm centres.

### FEATURES & BENEFITS

- Durable, lightweight, totally resistant to decay
- Easy to install as its laid continuously over the rafters before the underlay
- Supplied in 6m rolls
- Provides the equivalent of a continuous opening of not less than 10mm for the full length of the eaves.
- Universally adjusts to suit rafter centres
- Available in three widths—300, 600 and 800mm

### PRODUCT DETAILS

<b>Ventilation Area</b>	Max 25,000mm <sup>2</sup> per m
<b>Size</b>	Ventilation channels of at least 25mm
IRT300	Roll size 300mm x 6m Roll size 600mm x 6m Roll size 800mm x 6m
IRT600	
IRT800	
<b>Material</b>	Vacuum formed UPVC

<b>Colour</b>	Black
<b>Code</b>	IRT300, IRT600 & IRT800

