

# ICON Drill Vent IDV25

## Technical Data Sheet

Oct 2024

### PRODUCT



### Installation

- Low level vents should be installed min of 125mm below DPC . High level 200-225mm below soffit.
- Drill a 25mm hole typically at 750mm centres and both high and low level. The hole should be drilled at an angle upwards to accommodate the 2.5 degree angle of the vent.
- The angle will minimise any wind driven rain entering the cavity.
- Insert and align the drill vent so the louvres are correctly positioned.
- Tap the vent into hole using a rubber mallet.
- Drill vents should be flush with wall surface



**Note:** Spacing of drill vents for ventilation or drainage may vary depending on the specification, Building Regulation requirements, building type or location.

### USES

- For use in external walls
- Provides ventilation and drainage for cavity
- For use in timber framed buildings
- Installed after completion of external wall

### FEATURES & BENEFITS

- Provides ventilation and drainage without problems
- Eliminates damaged or locked weep vents during construction
- Used in new or refurbishment work
- Installed at an angle to prevent driving rain entering the cavity
- Quick and easy to install
- UV stable
- Available in Transparent, Beige and Terracotta
- Tested to EN13141-1
- Typically installed at 750mm c/c at high and low level. This may vary depending on building type, location, Building Regulations and specification.

### PRODUCT DETAILS



Free Area	250mm <sup>2</sup> per unit
Equivalent Area	137mm <sup>2</sup> tested at 4Pa outside to inside
Size	25mm hole 70mm long
Material	Injection moulded polypropylene
Colour	Transparent, Beige & Terracotta
Code	IDV25

