

#### n.v. P. Boonen & C<sup>o</sup> s.a. Rubber Products - Hoses - Couplings - Floorcoverings






Industrieterrein "Krekelenberg" - Tunnelweg 14 2845 Niel - Belgium Tel. 32 (0)3.844.25.29 - Fax. 32 (0)3.844.31.40 info@boonenp.be - www.boonenp.be

# ARPOL

# ARPOLINSTAL





flexible couplings for pipe connections



#### 🔻 A D V A N T A G E S


#### SIMPLICITY OF INSTALLATION


Complete unit. Ready for use. Low weight. Only one locking point. Quick assembly. Minimum space required. Economic solution.


#### FLEXIBILITY


Angular deflections. Axial movements. Radial deformations. Rough surfaces. Absorbs vibrations.


#### INSTALLATION instructions



















# A R P O L INSTAL

The flexible coupling for pipe connections of: Steel, Fiberglass Reinforced Plastics, Cast & Ductile Iron, HDPE, PVC, Asbestos Cement, Concrete, etc...

#### Suitable for:

Water treatment and distribution, industry, shipbuilding, construction and power stations.

#### Casing

Stainless steel Carbon steel with corrosion resistant coating.

Locking bolts and bars


Stainless steel Carbon steel with corrosion resistant coating.

#### **3** Sealing gasket


Synthetic rubber E.P.D.M. or N.B.R. Other materials on request.

ARPOL-INSTAL





**T** 



#### TECHNICAL CHARACTERISTICS

N.D. Nominal pipe diameter. O.D. Outside pipe diameter. bar Working pressure.

Test pressure = 1.5 x working pressure.



Nominal	width	95	mm	

O.D.	INOX Casing				
	Tolerance	Ref. <b>IBX</b>	АВ		
mm	mm	bar	mm mm		
48	47 - 49	16	78 31		
54	53 - 55	16	78 31		
57	56 - 58	16	78 31		
60	59 - 61	16	78 31		
63	62 - 65	16	78 31		
76	74 - 77	16	94 45		
84	82 - 85	16	94 45		
89	87 - 91	16	94 45		
104	102 - 106	16	94 45		
108	107 - 111	16	94 45		
114	112 - 117	16	95 45		
125	124 - 127	16	95 45		
129	127 - 131	16	95 45		
133	131 - 136	16	95 45		
139	137 - 142	16	95 45		
154	152 - 156	16	95 45		
159	156 - 161	16	95 45		
168	166 - 171	16	95 45		

	A	55	G.
())))))	1101.000		H
Ĭ			HA I
		CC	

#### Nominal width 140 mm

N.D.		INO	X Casin	g		STE	EL casi	ing
	Ref. IBY	Ref. ICY	Ref. IDY	Ref. IEY	Ref. IFY	Ref. ACY	Ref. AEY	Ref. AFY
mm	bar	bar	bar.	bar	bar.	bar	bar	bar
150	18	24	-	-	-	-	-	-
200	14	19	23	-	-	32	-	-
250	11	15	19	-	-	26	-	-
300	10	13	16	19	26	22	33	-
350	8	11	14	17	22	19	29	-
400	7	10	12	15	20	17	25	-
450	7	9	11	13	18	15	23	-
500	6	8	-	12	16	14	21	27
550	5	7	-	11	15	13	19	25
600	5	7	-	10	13	12	17	23
650	5	6	-	9	12	11	16	21
700	4	6	-	9	12	10	15	20
750	4	5	-	8	11	9	14	19
800	4	5	-	8	10	9	13	17
850	4	5	-	7	10	8	12	16
900	-	5	-	7	9	8	12	16
950	-	4	-	6	9	7	11	15
1000	-	4	-	6	8	7	-	-
1100	-	4	-	6	7	6	-	-
1200	-	3	-	6	7	6	-	-
Α	139	140	141	142	144	140	142	144
В	86	86	86	86	86	86	86	86

#### Nominal width 200 mm

N.D.		INO	X Casi	ng		STE	EL casi	ing
	Ref. IBZ	Ref. ICZ	Ref. IDZ	Ref. IEZ	Ref. IFZ	Ref. ACZ	Ref. AEZ	Ref. AFZ
mm	bar							
150	18	24	-	-	-	-	-	-
200	14	19	23	-	-	32	-	-
250	11	15	19	-	-	26	-	-
300	10	13	16	19	26	22	33	-
350	8	11	14	17	22	19	29	-
400	7	10	12	15	20	17	25	-
450	7	9	11	13	18	15	23	-
500	6	8	-	12	16	14	21	27
550	5	7	-	11	15	13	19	25
600	5	7	-	10	13	12	17	23
650	5	6	-	9	12	11	16	21
700	4	6	-	9	12	10	15	20
750	4	5	-	8	11	9	14	19
800	4	5	-	8	10	9	13	17
850	4	5	-	7	10	8	12	16
900	-	5	-	7	9	8	12	16
950	-	4	-	6	9	7	11	15
1000	-	4	-	6	8	7	11	14
1100	-	4	-	6	7	6	10	13
1200	-	3	-	5	7	6	9	12
1300	-	-	-	5	6	-	8	11
1400	-	-	-	4	6	-	8	10
1500	-	-	-	4	6	-	7	9
1600	-	-	-	4	5	-	7	9
1700	-	-	-	4	5	-	6	8
1800	-	-	-	3	5	-	6	8
1900	-	-	-	3	4	-	6	7
2000	-	-	-	3	4	-	5	7
Α	199	200	201	202	204	200	202	204
В	142	142	142	142	142	142	142	142
				1.1				

#### MATERIALS

#### Casing:

- Stainless steel AISI 304L or 316L.
- · Carbon steel Copolymer coated.

#### Locking bolts:

- Stainless steel AISI 316. · Carbon steel Dacromet coated.

#### Locking bars:

- Stainless steel AISI 304L or 316L.
  Carbon steel Dacromet coated.

#### Inner steel bridge:

Stainless steel AISI 304L or 316L.

#### Rubber sealing gasket:

- Synthetic rubber E.P.D.M. (ethylene-propylene). Suitable for water, air and chemical products.
- Temperature range from -20°C to +100°C.
- Synthetic rubber N.B.R. (nitrile-butadiene). Suitable for gas, oil, fuel and other hydrocarbons. Temperature range from -20°C a +80°C.

## A R P O L G Series

#### Nominal Width 200 mm

O.D. mm	INOX Casing	STEELCasing
	Ref. Ref. Ref. Ref. IGZ IGZR IGZ3 IGZ4	Ref. Ref. Ref. Ref. AGZ AGZR AGZ3 AGZ4
min. máx.	bar	bar
600 649	17	29
650 699	16	27
700 749	14	25
750 799	14	23
800 849	13	22
850 899	12	21
900 949	11	19
950 999	11	18
1000 1049	10	18
1050 1099	10	18
1100 1149	9	16
1150 1199	9	16
1200 1249	9	15
1250 1299	9	15
1300 1349	8	14
1350 1399	8	14
1400 1449	7	13
1450 1499	7	13
1500 1549	7	12
1550 1599	7	11
1600 1699	6	10
1700 1799	6	10
1800 1899	6	9
1900 1999	5	9
2000 2099	5	8
2100 2199	5	8
2200 2299	5	8
2300 2399	5	7
2400 2499	4	7
2500 2599	4	7
2600 2699	4	7
2700 2799	4	-
2800 2899	4	-
2900 2999	4	-

O.D. : Outside pipe diameter. bar: Working pressure.

Test pressure = 1.5 x working pressure.

#### MATERIALS

#### Casing:

- Stainless steel AISI 304L or 316L.
- Carbon steel Copolymer coated.

- Locking bolts: Stainless steel AISI 316.
- Carbon steel Dacromet coated.

#### Locking bars:

7


- Stainless steel AISI 304L or 316L.
- · Carbon steel Dacromet coated.

#### Inner steel bridge:

Stainless steel AISI 304L or 316L.

#### Rubber sealing gasket:

- Synthetic rubber E.P.D.M. (ethylene-propylene). Suitable for water, air and chemical products. Temperature range from -20°C to +100°C.
- · Synthetic rubber N.B.R. (nitrile-butadiene). Suitable for gas, oil, fuel and other hydrocarbons. Temperature range from -20°C a +80°C.





n.v. P. Boonen & C° s.a.

#### **ARPOL INSTAL** - Material specifications

#### Casing:

- f Stainless steel according to DIN 14301 (AISI 304) or DIN 14401 (AISI 316).
- *f* Carbon steel according to ST. 52.3 or equivalent, with Copolymer coating. The thermoplastic coating material chemical basis is an ethylene-vinyl-alcohol copolymer. Minimum film thickness: 0.250 mm.

#### Locking bolts:

- Stainless steel according to DIN 912, quality A2 or A4 (AISI 304 or AISI 316) coated to facilitate the fitting/removing process.
- Stainless steel according to DIN 912, quality A2 or A4 (AISI 304 or AISI 316).

#### Locking bars:

- *f* Stainless steel according to DIN 14301 (AISI 304) or DIN 14401 (AISI 316).
- f Gaged Carbon steel, quality C45K with additional Dacromet coating protection.

#### Inner Steel bridge (lock):

f Stainless steel according to DIN 14301 (AISI 304) or DIN 14401 (AISI 316).

#### Rubber sealing sleeve:

- *f* Synthetic rubber E.P.D.M. (ethylene-propylene).
  - Suitable for water, air and chemical products.
  - Temperature range: from -20°C to +100°C.
- f Synthetic rubber N.B.R. (nitrile-butadiene).
  - Suitable for gas, oil, fuel and other hydrocarbons.
  - Temperature range: from -20°C to +80°C.

#### ARPOL INSTAL - Permitted gaps between pipe ends

ARPOL couplings provide a flexible solution to join pipes. They can absorb:

- different outside diameters (please check limits in section "Joining Different O.D.")
- angular deflections (please check limits in section "Angular Deflections")
- axial movements (please check limits in section "Axial Movements")
- misalignment between pipe ends being joined (please check limits in section "Misalignment")
- gaps between pipe ends due to other reasons (please check limits in section "Permitted Gaps").


In all these cases, a gap between pipe ends is produced inside the coupling. If both the limits provided in the above mentioned sections and the following chart are met, the ARPOL coupling will absorb such gaps.

If gaps between pipes exceed certain limits (please check chart "Permitted gaps") a stainless steel band will have to be placed inside the coupling between the rubber sealing sleeve lips (see drawing).

Moreover, such band is also required in vacuum lines or with vacuum risk, unless gaps between pipe ends can be avoided.

Should you need the stainless steel band, please consult us.


PERMITTED					
GAPS A					
Coupling	No	With			
Width	Insert	Insert			
(mm)	(mm)	(mm)			
75	5	15			
95	5	15			
140	10	35			
200	15	60			



#### **ARPOL INSTAL** - Maximum admissible tolerance

When joining pipes of the same O.D., ARPOL INSTAL maximum admissible tolerances are as follows:

MAXIMUM TOLERANCE Joining pipes of the same O.D.				
Coupling Width (mm)	Outside Diameter (mm)	Tolerance Range (mm)		
		Standard		
75 - 95	48 a 171	Values		
140 - 200	156 a 499	6		
140 - 200	> 499	8		



For information on standard sizes for 75 – 95 mm width couplings, please check the ARPOL INSTAL catalogue.


Should you need higher tolerances, please consult the possibilities of ARPOL REP-2 or ARPOL REP-3 as they offer higher values (see technical documentation or please consult us).

When using ARPOL INSTAL couplings to join different O.D., please check the "Joining Different O.D. Pipes" section on the maximum admissible tolerances.

#### **ARPOL INSTAL** - Joining Different O.D.

O.D. differences between adjacent and CONCENTRIC pipes to be joined should not exceed:

JOINING DIFFERENT O.D.					
Outside Diameter (mm)	Maximum Difference X (mm)				
48	0,5				
54 a 63	1,0				
76 a 104	1,5				
106 a 499	2,5				
> 499	3,0				



Should you have higher O.D. differences, please consult the possibilities of other ARPOL couplings



# n.v. P. Boonen & C° s.a.

#### **ARPOL INSTAL** - Misalignment


Joining misaligned pipes with ARPOL INSTAL:

MISA	LIGNMENT				
Outside Diameter (mm)	Maximum Difference (mm)	σ	0	9	
<300	1%	D. x ()			
≥300	3 mm	7-	- · - · - · - ·  - · -	•••••	+*-

#### **ARPOL INSTAL** - Permitted axial movements

The sum of axial movements caused by pipe extension or contraction between **two fix points** should not exceed:

AXIAL MOVEMENT					
Coupling Width (mm)	Max. Movement (mm)				
75 - 95	5				
140	10				
200	15				




#### **ARPOL INSTAL** - Angular deflection

ARPOL INSTAL couplings allow certain amount of angular deflection between pipe ends. The maximum admissible tolerance permitted by ARPOL couplings depends on the O.D. of pipes (see enclosed chart).

ANGULAR DEFLECTION				
Outside Diameter	Maximum			
(mm)	Deflection * ເ			
<1500	2°			
<u>&gt;</u> 1500	1º			


\* Please consult for higher rates



#### **ARPOL INSTAL** - Lateral displacement

Lateral displacement between two pipes can be accommodated using two ARPOL couplings and a closing pipe. The length of the closing pipe can be calculated as follows:


dd = lateral displacement to be accommodatedL = ------L = length of the closing pipeSen ßß = deviation (check maximum limits in "Angular Deflection")



#### **ARPOL INSTAL** - Pipe holders

Aerial pipelines require holders on both sides of the coupling.

ARPOL INSTAL couplings are not designed to stand neither weight nor axial stress of pipes, therefore the pipeline must be properly fixed and supported. Should you need more information, please consult us.



n.v. P. Boonen & C° s.a.

#### **ARPOL INSTAL** - Fitting instructions

All ARPOL couplings are supplied with the following basic fitting instructions on the label:

- ARPOL reference which includes the tolerance. Should different O.D. be joined, please check admissible values.
- *f* Working Pressure (bar)
- f Test Pressure = **1,5** working pressure
- f Torque value (N/m)

In order to enable the ARPOL coupling to work correctly it is very important to respect the torque value.

To fit the ARPOL INSTAL couplings, we recommend following these steps:

- 1 f Clean pipe ends and eliminate any irregularity.
- 2 *f* Mark both pipe ends symmetrically at a distance from the edge equivalent to half of the coupling width.
- 3 f Slide the coupling over one pipe end.
- 4 *f* Bring the other pipe end to a facing position. Make sure the alignment limits as well as angular deflection, etc., are respected and that both pipe ends are correctly held.
- 5 *f* Place the coupling between the marks and check that the inner steel bridge is correctly placed under the lock.
- 6 f Tighten screws:
  - 6.1. Start the tightening of screws using a click wrench with a nozzle.
    - 2 screws lock: tighten both screws by alternative short movements until you nearly reach the end, but do not exceed the torque value.
    - **3 screws lock**: First tighten the central screw up to **10** mm. Then tighten exterior screws positioning them at the same level as the central screw. Keep tightening the three screws by alternative short movements until you nearly reach the end, but **do not exceed the torque value**.
  - 6.2. Finish the tightening with a dynamometric wrench with sound signal.
    - Adjust the wrench to **the torque value printed on the coupling label**. Keep tightening screws alternatively with the dynamometric wrench until you can hear the 'click sound' at the beginning of the tightening.
- 7 *f* If necessary, you may hydraulically test the coupling up to 1.5 the working pressure (see label).

	Outside Diamete (mm)		n Difference X (mm)
	48 54 a 63		0,5 1,0
( ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	76 a 104		1,5
	106 a 499 > 499		2,5 3,0
	Coupling Width (mm)	No Internal Band (mm)	With Internal Band (mm)
QQ	75 - 95	5	15
	140	10	35
	200	15	60
	Outside Diam (mm)		mum jnment
	< 300	1	%
	<u>&gt;</u> 300	3 r	nm
	Outside Diame (mm)	eter Max. A Deflec	-
	< 1500	2	0
	<u>&gt;</u> 1500	1	0
	* Please consult	for higher value	S
		d	
	L = Se	 en <b>ß</b>	
	d = wisł	ned displacemer	nt
		of the closing	
	ß=dev	iation (check lim	its)
RPOL INSTAL couplings are not designed to	support the pipe or to pr	event axial mov	ements. Therefore
e pipe must be properly supported and ancho	ored.		

# ARPOLREP





# flexible couplings for pipe repair





#### 🔍 A D V A N T A G E S

SIMPLICITY OF INSTALLATION Repair without pipe replacement. Low weight. Quick assembly. Minimum space required. Economic solution.


#### FLEXIBILITY


Rough surfaces. Radial deformation. Angular deflections. Axial movements. Absorbs vibrations.








# INSTALLATION instructions
















#### ARPOL REPAIR SYSTEM

**1.** By mounting the ARPOL coupling around the damaged pipe surface.








2. By eliminating the damaged joint and mounting the ARPOL on both pipe ends.

		$\sim$	]	_
_				-
			6	
ut and	remo	ove ti	he sock	et
at ana				



remove the joint











#### SEALING

As the pressure rises, the seal is increased proportionately. The coupling adapts automatically to internal pressure changes.









# <u>ARPOL</u>REP


The flexible coupling for pipe repairs of: Steel, Fiberglass Reinforced Plastics, Cast & Ductile Iron, HDPE, PVC, Asbestos Cement, Concrete, etc...

Maintenance for:

3

Water treatment and distribution, industry, ship repair, construction and power stations.

**Casing** Stainless steel. Carbón steel with corrosion resistant coating.



Sealing gasket Synthetic rubber E.P.D.M. or N.B.R. Other materials on request.


















A R P O L - R E P with outlet

- Outlet: with inside thread.
- Working pressure: up to 10 bar.
- Available from O.D. 250 mm.
- Only available as 2 or 3-lock stainless steel couplings AISI 304L or 316L.

		ARPOL REP WITH OUTLET						
Outlet				2,5"	3"	4"		
Width of coupling	140 mm 200 mm	140 mm 200 mm	140 mm 200 mm	200 mm	200 mm	200 mm		

#### TECHNICAL CHARACTERISTICS

N.D. Nominal pipe diameter. O.D. Outside pipe diameter. bar Working pressure.

Test pressure = 1.5 x working pressure.



#### Nominal width 95 mm

0.D.		INOX Casing			
1 e e e	Ref. IBXR	Ref. IBXC		A	в
mm	Tolerance mm	Tolerance mm	bar	mm	mm
48		47 - 49	16	78	31
54		53 - 55	16	78	31
57		56 - 58	16	78	31
60		59 - 61	16	78	31
63	60 - 64	62 - 65	16	78	31
76	74 - 78	74 - 77	16	94	45
84	80 - 86	82 - 85	16	94	45
89	87 - 93	87 - 91	16	94	45
104	98 - 106	102 - 106	16	94	45
108	107 - 111	107 - 111	16	94	45
114	110 - 116	112 - 117	16	94	45
125	118 - 125	124 - 127	16	94	45
129	125 - 131	127 - 131	16	94	45
133	131 - 136	131 - 136	16	94	45
139	137 - 144	137 - 142	16	94	45
154	147 - 156	152 - 156	16	94	45
159	156 - 162	156 - 161	16	94	45
168	166 - 171	166 - 171	16	94	45
100	100 - 171	100 - 171	10	94	43

#### Nominal width 140 mm

Nomin			Jmm					
N.D.	INOX Casing					STE	EL cas	ing
	Ref. IBYR	Ref. ICYR	Ref. IDYR	Ref. IEYR	Ref. IFYR	Ref. ACYR	Ref. AEYR	Ref. AFYR
mm	bar							
150	18	24	-	-	-	-	-	-
200	14	19	23	-	-	32	-	-
250	11	15	19	-	-	26	-	-
300	10	13	16	19	26	22	33	-
350	8	11	14	17	22	19	29	-
400	7	10	12	15	20	17	25	-
450	7	9	11	13	18	15	23	-
500	6	8	10	12	16	14	21	27
550	5	7	9	11	15	13	19	25
600	5	7	8	10	13	12	17	23
650	5	6	8	9	12	11	16	21
700	4	6	7	9	12	10	15	20
750	4	5	-	8	11	9	14	19
800	4	5	-	8	10	9	13	17
850	4	5	-	7	10	8	12	16
900	3	5	-	7	9	8	12	16
950	3	4	-	6	9	7	11	15
1000	-	4	-	6	8	7	-	-
1100	-	4	-	6	7	6	-	-
1200	-	3	-	5	7	6	-	-
Α	139	140	141	142	144	140	142	144
В	86	86	86	86	86	86	86	86

#### Nominal width 200 mm

N.D.		INC	ST	EEL cas	sin			
	Ref. IBZR	Ref. ICZR	Ref. IDZR	Ref. IEZR	Ref. IFZR	Ref. ACZR	Ref. AEZR	ļ
mm	bar							
150	18	24	-	-	-	-	-	
200	14	19	23	-	-	32	-	
250	11	15	19	-	-	26	-	
300	10	13	16	19	26	22	33	
350	8	11	14	17	22	19	29	
400	7	10	12	15	20	17	25	
450	7	9	11	13	18	15	23	
500	6	8	10	12	16	14	21	
550	5	7	9	11	15	13	19	
600	5	7	8	10	13	12	17	
650	5	6	8	9	12	11	16	
700	4	6	7	9	12	10	15	
750	4	5	-	8	11	9	14	
800	4	5	-	8	10	9	13	
850	4	5	-	7	10	8	12	
900	3	5	-	7	9	8	12	
950	3	4	-	6	9	7	11	
1000	-	4	-	6	8	7	11	
1100	-	4	-	6	7	6	10	
1200	-	3	-	5	7	6	9	
1300	-	3	-	5	6	5	8	
1400	-	3	-	4	6	5	8	
1500	-	3	-	4	6	5	7	
1600	-	2	-	4	5	4	7	
1700	-	2	-	4	5	4	6	
1800	-	2	-	3	5	-	6	
1900	-	-	-	3	4	-	6	
2000	-	-	-	3	4	-	5	
Α	199	200	201	202	204	200	202	
В	142	142	142	142	142	142	142	

Please consult us for sizes bigger than 2000 mm.

#### MATERIALS

#### Casing:

 Stainless steel AISI 304L or 316L. · Carbon steel Copolymer coated.

#### Locking bolts:

- Stainless steel AISI 316.
   Carbon steel Dacromet coated.

#### Locking bars:

- Stainless steel AISI 304L or 316L.
- · Carbon steel Dacromet coated.

Inner steel bridge: • Stainless steel AISI 304L or 316L.

#### Rubber sealing gasket:

- Synthetic rubber E.P.D.M. (ethylene-propylene). Suitable for water, air and chemical products. Temperature range from -20°C to +100°C.
- Synthetic rubber N.B.R. (nitrile-butadiene). Suitable for gas, oil, fuel and other hydrocarbons. Temperature range from  $-20^{\circ}Ca + 80^{\circ}C$ .

### A R P O L <mark>G Series</mark>

#### Nominal Width 200 mm

O.D. mm	h 200 mm INOX Casing	STEELCasing
	Ref. Ref. Ref. Ref. IGZ IGZR IGZ3 IGZ4	Ref. Ref. Ref. Ref. AGZ AGZR AGZ3 AGZ4
min. máx.	bar	bar
600 649	17	29
650 699	16	27
700 749	14	25
750 799	14	23
800 849	13	22
850 899	12	21
900 949	11	19
950 999	11	18
1000 1049	10	18
1050 1099	10	18
1100 1149	9	16
1150 1199	9	16
1200 1249	9	15
1250 1299	9	15
1300 1349	8	14
1350 1399	8	14
1400 1449	7	13
1450 1499	7	13
1500 1549	7	12
1550 1599	7	11
1600 1699	6	10
1700 1799	6	10
1800 1899	6	9
1900 1999	5	9
2000 2099	5	8
2100 2199	5	8
2200 2299	5	8
2300 2399	5	7
2400 2499	4	7
2500 2599	4	7
2600 2699	4	7
2700 2799	4	-
2800 2899	4	-
2900 2999	4	-

**O.D.** : Outside pipe diameter. **bar**: Working pressure.

Test pressure = 1.5 x working pressure.

#### MATERIALS

#### Casing:

- Stainless steel AISI 304L or 316L.
- Carbon steel Copolymer coated.

#### Locking bolts:

- Stainless steel AISI 316.
- Carbon steel Dacromet coated.

#### Locking bars:


Stainless steel AISI 304L or 316L.
Carbon steel Dacromet coated.

#### Inner steel bridge:

Stainless steel AISI 304L or 316L.

#### Rubber sealing gasket:

- Synthetic rubber E.P.D.M. (ethylene-propylene). Suitable for water, air and chemical products. Temperature range from -20°C to +100°C.
- Synthetic rubber N.B.R. (nitrile-butadiene). Suitable for gas, oil, fuel and other hydrocarbons. Temperature range from -20°C a +80°C.



#### ARPOL REP 2 - Material specifications

#### Casing:

- *f* Stainless steel according to DIN 14301 (AISI 304) or DIN 14401 (AISI 316).
- *f* Carbon steel according to ST. 52.3 or equivalent, with Copolymer coating. The thermoplastic coating material chemical basis is an ethylene-vinyl-alcohol copolymer. Minimum film thickness: 0.250 mm.

#### Locking Bolts:

- Stainless steel according to DIN 912, quality A2 or A4 (AISI 304 or AISI 316) coated to facilitate the fitting/removing process.
- f Stainless steel according to DIN 912 with additional Dacromet coating protection.

#### Locking Bars:

- f Stainless steel according to DIN 14301 (AISI 304) or DIN 14401 (AISI 316).
- f Gaged Carbon steel, quality C45K with additional Dacromet coating protection.

#### Inner Steel bridge:

f Stainless steel according to DIN 14301 (AISI 304) or DIN 14401 (AISI 316).

#### Rubber sealing sleeve:

- f Synthetic rubber E.P.D.M. (ethylene-propylene)
  - Suitable for water, air and some chemical products.
  - Temperature range: from -20°C to +100°C.
- f Synthetic rubber N.B.R. (nitrile-butadiene)
  - Suitable for gas, fuel and other hydrocarbons.
  - Temperature range: from -20°C to +80°C.



#### ARPOL REP 2 - Permitted gaps between pipe ends

ARPOL couplings provide a flexible solution to join pipes. They can absorb:

- different outside diameters (please check limits in section "Joining Different O.D.")
- angular deflections (please check limits in section "Angular Deflections")
- axial movements (please check limits in section "Axial Movements")
  - misalignment between pipe ends being joined (please check limits in section "Misalignment")
- gaps between pipe ends due to other reasons (please check limits in section "Permitted Gaps")


In all these cases, a gap between pipe ends is produced inside the coupling. If both the limits provided in the above mentioned sections and the following chart are met, the ARPOL coupling will absorb such gaps.

If gaps between pipes exceed certain limits (please check chart "Permitted gaps") a stainless steel band will have to be placed inside the coupling between the rubber sealing sleeve lips (see drawing).

Moreover, **such band is also required in vacuum lines or with vacuum risk,** unless gaps between pipe ends can be avoided.

Should you need the stainless steel band, please consult us. 5

PERMITTED GAPS A							
Coupling	No	With					
Coupling Width (mm)	Internal	Internal					
	Band	Band					
(((((((((((((((((((((((((((((((((((((((	(mm)	(mm)					
75	5	15					
95	5	15					
140	10	35					
200	15	60					
200	15	60					



#### ARPOL REP 2 - Maximum admissible tolerance

When joining pipes of the same O.D., ARPOL REP 2 maximum admissible tolerances are as follows:

Ø Max

Ø Mir

MAXIMUM TOLERANCE Joining pipes of the same o.d.					0	9
oupling With (mm)	Outside Diameter (mm)	Tolerance Range (mm)	3	! ! !		
		Standard		ļ		
75 - 95	60 a 171	Values		!		
140 - 200	156 a 499	12		<u> </u>		
140 - 200	> 499	16		:		UUL

For information on standard sizes for 75 – 95 mm width couplings, please check the ARPOL REP catalogue.

Should you need higher tolerances, please consult the possibilities of ARPOL REP-3 as it offers higher values (see technical documentation or please consult us).

When using ARPOL REP 2 couplings to join different O.D., please check the "Joining Different O.D. Pipes" section on the maximum admissible tolerances.

#### ARPOL REP 2 - Joining Different O.D.

O.D. differences between adjacent and **concentric** pipes to be joined should not exceed:




JOINING D	DIFFERENT O.D.		9	0		X ÷ 2
Outside Diameter (mm)	Maximum Difference X (mm)	<u> </u>				(
60 a 64	2,0	2			↓	
76 a 104	3,0	6		<u>م</u>		X ÷ 2
106 a 499	5,0	-			Т	/ · · ·
> 499	6.0	10				

Should you have higher O.D. differences, please consult the possibilities of ARPOL REP-3 as it offers higher values (see technical documentation or please consult us).

# n.v. P. Boonen & C° s.a.

#### ARPOL REP 2 - Joining misaligned pipes


Joining misaligned pipes with ARPOL REP 2:



#### ARPOL REP 2 - Permitted axial movements

The sum of axial movements caused by pipe extension or contraction between **two fixed points** should not exceed:


AXIAL M	OVEMENT
Coupling Width (mm)	Max. Movement (mm)
75 - 95	5
140	10
200	15



#### ARPOL REP 2 - Angular deflection

ARPOL REP 2 couplings allow certain amount of angular deflection between pipe ends. The maximum admissible tolerance permitted by ARPOL couplings depends on the O.D. of pipes (see enclosed chart).

ANGULAR DEFLECTION						
Outside Diameter (mm)	Maximum Deflection * ß					
<1500	2°					
<u>&gt;</u> 1500	1°					



\* Please consult for higher rates

#### ARPOL REP 2 - Lateral displacement


Lateral displacement between two pipes can be accommodated using two ARPOL couplings and a closing pipe. The length of the closing pipe can be calculated as follows:

d

\_\_\_\_\_

L =

- d = lateral displacement to be accommodated
  - L = length of the closing pipe
- **Sen ß** = deviation (check maximum limits in "Angular Deflection")



#### ARPOL REP 2 - Pipe holders

ARPOL-REP 2 couplings are not designed to stand neither weight nor axial stress of pipes, therefore the pipeline must be properly fixed and supported. Should you need more information, please consult us.

#### ARPOL REP 2 - Fitting and removing couplings


One of the main characteristics of ARPOL couplings is they can be fitted and removed several times. Should the removal take place after a year of working performance, we recommend having the rubber substituted.

#### ARPOL REP 2 - Permitted break widths

ARPOL REP 2 couplings are not fitted by sliding them from the pipe end. Instead, they can be fitted directly on the break point without having to cut the pipe.

For this application the maximum permitted break widths are as follows:

MAXIMUM BREAK WIDTH					
Coupling Width A (mm)	Max. Break <b>R</b> (mm)				
75	20				
95	35				
140	50				
200	100				



#### **ARPOL REP 2** - FITTING INSTRUCTIONS

All ARPOL couplings are supplied with the following basic fitting instructions on the label:

- *f* ARPOL reference which includes the tolerance. Should different O.D. be joined, please check admissible values.
- f Working Pressure (bar)
  - Test Pressure = 1,5 working pressure
- f Torque value (N/m)

f

### In order to enable the ARPOL coupling to work correctly it is very important to respect the torque value.

To fit the ARPOL REP 2 couplings, we recommend following these steps:

- 1 *f* Clean and eliminate any irregularity that may be on the break area or the pipe ends.
- 2 *f* Unfasten the coupling by the lock with o-ring seals on the screws. Slide the rubber band around the pipe. Following the rubber line, make sure the rubber ends are correctly aligned on the upper side, **not overlapped**. Hold the rubber band (with some adhesive tape, for instance). **DO NOT CUT THE RUBBER BAND**.
- 3 *f* Place the inner steel bridge on the rubber band. Make sure they are correctly imbedded and facing each other at both sides of the coupling. The line of the rubber ends should be perpendicular to the lock.
- 4 *f* Place both parts of the casing on the rubber band. The inner steel bridge should rest under the locks. Fit screws and anchors. When locking the coupling, double-check the rubber band is aligned, not overlapped, and the steel bridges are correctly placed under the lock.
- 5 f Tighten screws:
  - 5.1. Start the tightening of screws using a click wrench with a nozzle.
    - 2 screws lock: tighten both screws by alternative short movements until you nearly reach the end, but do not exceed the torque value.
    - 3 screws lock: First tighten the central screw up to 10 mm.
       Then tighten exterior screws positioning them at the same level as the central screw.
       Keep tightening the three screws by alternative short movements until you nearly reach the end, but do not exceed the torque value.
  - 5.2. Finish the tightening with a dynamometric wrench with sound signal.
    - Adjust the wrench to the torque value printed on the coupling label. Keep tightening screws alternatively with the dynamometric wrench until you can hear the 'click sound' at the beginning of the tightening.
- 6 f If necessary, you may hydraulically test the coupling up to 1.5 the working pressure (see label).

28

() <b>() x</b> ÷ 2	Outside Diam (mm)	eter Maximu	um Difference X (mm)	
✓	76 a 168		3,0	
<b> ▲</b> X÷2	169 a 499 > 499		5,0 6,0	
	Coupling Width (mm)	No Internal Band (mm)	With Internal Band (mm)	
YQ	75 - 95	5	15	
	140	10	35	
	200	15	60	
	Outside Diameter (mm)		Maximum Misalignment	
	< 3(	00	1%	
	<u>&gt;</u> 30	00	3 mm	
			lax. Angular Deflection *	
	< 1	500	2°	
	<u>≥</u> 1	500	1°	
	* Please c	onsult for highe	r values	
		ng Width nm)	Max. Break A (mm)	
		75	20	
		95	35	
		40	50	
	2	00	100	

Couplings applied on vacuum lines or with vacuum risk require an internal band unless gaps between pipes can be avoided. Please consult us in this situation.

AR	POL REP C				
	Outside Diameter (mm)	Maximum Difference (mm)			
	48		0,5		
	54 a 63		1,0		
X+2	76 a 104		1,5		
	106 a 499 > 499		2,5 3,0		
		internal nd (mm)	With Internal Band (mm)		
₽₽	75 - 95	5	15		
	140	10	35		
	200	15	60		
	Outside Diameter (mm)		mum Inment		
₽ <u> </u>	< 300	1	1%		
	≥ 300	3 n	3 mm		
	Outside Diameter (mm)	Max. A Deflec			
	< 1500	2	D		
	≥ 1500	1			
	* Please consult for I	higher value	5		
	Coupling Widt (mm)		Break mm)		
	75	2	20		
		35			
9	95	3	35		
			35 50		

n.v. P. Boonen & C° s.a.

ARPOL REP C couplings are not designed to support the pipe or to prevent axial movements. Therefore, the pipe must be properly supported and anchored.

Couplings applied on vacuum lines or with vacuum risk require an internal band unless gaps between pipes can be avoided. Please consult us in this situation.

() () x÷2	Outside Diam (mm)	Outside Diameter Maxim (mm)		
	220 a 499		7,0	
	> 499		8,0	
	Coupling Width (mm)	No Internal Band (mm)	With Internal Band (mm)	
	140	10	35	
	200	15	60	
		e Diameter nm)	Maximum Misalignment	
₽	220	a 499	2,5 mm	
	>	499	3,0 mm	
		Diameter nm)	Max. Angular Deflection *	
	< ^	1500	2°	
	<u>≥</u> 1	1500	1°	
	* Please of	consult for high	er values	
	Coupli	ng Width	Max. Break	
	(r	nm)	A (mm)	
	1	40	50	
		00	100	

U

J

Couplings applied on vacuum lines or with vacuum risk require an internal band unless gaps between pipes can be avoided. Please consult us in this situation.

# ARPOLFIX





# flexible couplings for pipe connections with axial restraint



#### 🔻 A D V A N T A G E S

#### SIMPLICITY OF INSTALLATION Complete unit. Ready for use. Low weight.

Only one locking point. Quick assembly.

#### **REPLACES:**


Welding. Flanging. Threading. Screwing.

#### MORE ECONOMICAL Quick assembly. Minimum space required.


#### FLEXIBILITY


Angular deflections. Axial movements. Absorbs vibration. Conducts electricity.

















#### A P P L I C A T I O N S





















As the pressure rises, the seal is increased proportionately The coupling adapts automatically to internal pressure changes







# A R P O L <mark>F I X</mark>



Suitable for: Water treatment and distribution, industry, shipbuilding, construction, power stations.

Casing Stainless steel.

Locking bolts and bars Stainless steel. Carbon steel with corrosion resistant coating.

Axial restraint internal parts Stainless steel.

Sealing gasket Synthetic rubber E.P.D.M. or N.B.R. Other materials on request.

#### ARPOL-FIX

#### 🖊 MATERIALS

#### Casing:

Stainless steel AISI 304L or AISI 316L.

#### Locking bolts:

- Stainless steel AISI 316.
- Carbon steel Dacromet coated.

#### Locking bars:

- Stainless steel AISI 304L or AISI 316L.
- Carbon steel Dacromet coated.

#### Inner steel bridge:

Stainless steel AISI 304L or AISI 316L.

#### Internal rings:

Stainless steel.

#### Rubber sealing gasket:

- Synthetic rubber E.P.D.M. (ethylene-propylene). Suitable for water, air and chemical products. Temperature range from -20<sup>o</sup>C to +100<sup>o</sup>C.
- Synthetic rubber N.B.R. (nitrile-butadiene). Suitable for gas, oil, fuel and other hydrocarbons. Temperature range from -20°C a +80°C.



#### A N C H O R I N G 🔻

When the locking bolts are tightened to the indicated torque, the anchor teeth grip into the surface of the pipe.



#### TECHNICAL CHARACTERISTICS

**O.D.** = Outside pipe diameter.


ARPOL-FIX-L

4

Suitable for higher working pressures (please consult us). Test pressure = 1,5 x working pressure.

Intermediate size from O.D. 200 mm available (upon request).

Angular deflections permitted: 2<sup>0</sup> in any direction.



METAL PIPES

Ŧ

<b>↓</b>		Δ	Λ			7	I ▼
O.D.	Tolerance	Working	Di	mensio	ns	Во	Its
	range	pressure	Α	В	D	No.	Dia.
mm	mm	bar	mm	mm	mm		mm
48,3	47,8 - 48,9	16	93	31	76	2	M8
54,0	53,5 - 54,5	16	93	31	82	2	M8
57,0	56,4 - 57,6	16	93	31	85	2	M8
60,3	59,7 - 60,9	16	93	31	88	2	M8
76,1	75,3 - 76,9	16	112	45	104	2	M10
84,0	83,1 - 84,9	16	112	45	112	2	M10
88,9	88,0 - 89,8	16	112	45	119	2	M10
104,0	102,9 - 105,1	16	113	45	137	2	M10
108,0	106,9 - 109,1	16	113	45	141	2	M10
114,3	113,2 - 115,4	16	113	45	147	2	M10
129,0	127,8 - 130,2	16	113	45	163	2	M10
133,0	131,7 - 134,3	16	114	45	167	2	M10
139,7	138,3 - 141,1	16	114	45	184	2	M10
154,0	152,4 - 155,6	16	114	45	188	2	M10
159,0	157,4 - 160,6	16	114	45	193	2	M10
168,3	166,6 - 170,0	16	114	45	202	2	M10
219,1	216,9 - 221,3	16	144	86	255	3	M12
244,5	242,0 - 247,0	9	144	86	280	3	M12
267,0	264,5 - 269,5	8	144	86	303	3	M12
273,0	270,5 - 275,5	8	144	86	309	3	M12
323,9	320,5 - 327,0	6	144	86	360	3	M12
355,6	352,0 - 359,0	6	144	86	391	3	M12
406,4	402,5 - 410,5	5	144	86	441	3	M12



↓		Λ	Λ			1	V	
O.D.	Tolerance	Working	Di	mensic	ons	Во	lts	
	range	pressure	Α	В	D	No.	Dia.	
mm	mm	bar	mm	mm	mm		mm	
48,3	47,8 - 48,9	16	78	31	68	2	M8	
54,0	53,5 - 54,5	16	78	31	74	2	M8	
57,0	56,4 - 57,6	16	78	31	77	2	M8	
60,3	59,7 - 60,9	16	78	31	80	2	M8	
76,1	75,3 - 76,9	16	94	45	96	2	M8	
84,0	83,1 - 84,9	16	94	45	104	2	M8	
88,9	88,0 - 89,8	16	94	45	112	2	M8	
104,0	102,9 - 105,1	16	94	45	127	2	M8	
108,0	106,9 - 109,1	16	94	45	131	2	M8	
114,3	113,2 - 115,4	16	95	45	137	2	M8	
129,0	127,8 - 130,2	16	95	45	152	2	M10	
133,0	131,7 - 134,3	16	95	45	156	2	M10	
139,7	138,3 - 141,1	16	95	45	163	2	M10	
154,0	152,4 - 155,6	14	96	45	178	2	M10	
159,0	157,4 - 160,6	14	96	45	183	2	M10	
168,3	166,6 - 170,0	13	96	45	191	2	M10	
219,1	216,9 - 221,3	10	141	86	251	3	M12	
244,5	242,0 - 247,0	5,5	141	86	276	3	M12	
267,0	264,5 - 269,5	5	141	86	299	3	M12	
273,0	270,5 - 275,5	4,5	141	86	305	3	M12	
323,9	320,5 - 327,0	3	141	86	356	3	M12	
355,6	352,0 - 359,0	2,5	141	86	387	3	M12	
406,4	402,5 - 410,5	2	141	86	438	3	M12	
457,0	455,6 - 461,7	2	141	86	489	3	M12	
508,0	504,2 - 512,5	1,5	141	86	540	3	M12	
558,0	553,4 - 564,2	1,5	141	86	590	3	M12	
609,0	604,2 - 615,0	1	141	86	641	3	M12	

ARPOL-FIX-U

A R P O L - F I X - M

METAL AND PLASTIC PIPES

METAL PIPES

			/		<u> </u>	/			
			•	•	P				
		* *					· · ·	Í 7	
	O.D.	Tolerance	Working	Di	mensic	ns	Bolts		
		range	pressure	Α	В	D	No.	Dia.	
	mm	mm	bar	mm	mm	mm		mm	
	63	62,0 - 64,0	16	99	31	89	2	M8	
	75	74,0 - 76,0	16	117	45	103	2	M8	
	90	89,0 - 91,0	16	117	45	118	2	M8	
	110	108,0 - 111,0	16	117	45	138	2	M8	
	125	123,0 - 126,0	16	118	45	153	2	M10	
	140	138,0 - 142,0	16	118	45	168	2	M10	
	160	158,0 - 162,0	16	118	45	188	2	M10	
	180	178,0 - 182,0	16	200	100	227	3	M12	
	200	198,0 - 203,0	16	201	100	247	3	M12	
	225	222,0 - 227,0	16	201	100	272	3	M12	
	250	247,0 - 253,0	16	201	100	297	3	M12	
	280	277,0 - 283,0	10	202	100	328	3	M12	
	315	311,0 - 317,0	10	202	100	363	3	M12	
	355	351,0 - 357,0	10	204	100	405	3	M16	
	400	396,0 - 402,0	10	204	100	450	3	M16	
	450	446,0 - 452,0	6	204	100	500	3	M16	
	500	496,0 - 503,0	4	204	100	550	3	M16	
200	VALUE	ES FOR PLASTIC	PIPES						

Flexible pipes may require reinforcing inserts. For use on metal pipes or for joining different pipe materials, please consult.

## **ARPOL FIX** - Material specifications

#### Casing:

- f Stainless steel according to DIN 14301 (AISI 304) or DIN 14401 (AISI 316).
- *f* Carbon steel according to ST. 52.3 or equivalent, with Copolymer coating. The thermoplastic coating material chemical basis is an ethylene-vinyl-alcohol copolymer. Minimum film thickness: 0.250 mm.

#### Locking Bolts:

- *f* Stainless steel according to DIN 912, quality A2 or A4 (AISI 304 or AISI 316) coated to facilitate the fitting/removing process.
- f Stainless steel according to DIN 912 with additional Dacromet coating protection.

#### Locking Bars:

- f Stainless steel according to DIN 14301 (AISI 304) or DIN 14401 (AISI 316).
- f Gaged Carbon steel, quality C45K with additional Dacromet coating protection.

#### Inner Steel bridge:

f Stainless steel according to DIN 14301 (AISI 304) or DIN 14401 (AISI 316).

#### Anchor Ring:

f Stainless steel (AISI 302)

#### Support Ring:

- FIX-M: Stainless steel (AISI 301)
- *f* FIX-U: Stainless steel (AISI 316)

#### Rubber sealing sleeve:

- *f* Synthetic rubber **E.P.D.M.** (ethylene-propylene)
  - Suitable for water, air and some chemical products.
  - Temperature range: from -20°C to +100°C.
- f Synthetic rubber N.B.R. (nitrile-butadiene)
  - Suitable for gas, fuel and other hydrocarbons.
  - Temperature range: from -20°C to +80°C.

AR	POL FIX-L					
	Outside Diam (mm)	eter Max	kimum Difference X (mm)			
₩ ₩ x ÷ 2	48		0,5 1,0 1,5 2,5 3,0			
YQ	54 a 63					
	76 a 104					
	106 a 499	1				
	> 499					
	Coupling Width (mm)	No Inter Band (m				
	75 - 95	5	15			
	140	10	35			
	Outside E (mr		er Maximum Misalignment			
¥↓↓★↓	< 31	00	1%			
	<u>&gt;</u> 3		3 mm			
	Outside D (mn		Max. Angular Deflection *			
	48 a 6	48 a 600				
	* Please co	nsult for higl	ner values			
		d				
d → B → B → d → d	_ L = -	Sen <b>ß</b>				
	.Q. d = wi	shed displa	cement			
	1	ngth of the c				
		eviation (che				

ab n.v. P. Boonen & C° s.a.

ARPOL FIX-L couplings are designed to stand axial stress of metallic pipes, however the pipeline must be properly supported. Should you need more information, please consult us

Couplings applied on vacuum lines or with vacuum risk require an internal band unless gaps between pipes can be avoided. Please consult us in this situation.

	Outside Diame (mm)	eter Maximur	Maximum Difference X (mm)		
	48		0,5		
YY	54 a 63		1,0		
↓ ↓ X÷2	76 a 104		1,5		
	106 a 499		2,5		
	> 499		3,0		
	Coupling Width (mm)	No Internal Band (mm)	With Internal Band (mm)		
YY	93 - 114	5	15		
	140	10	35		
	Outside Dia		Maximum Misalignment		
	(mm)				
<pre></pre>	< 300		1%		
	<u>≥</u> 300	)	3 mm		
	Outside Dia (mm)		Angular ection *		
20 4	48 a 60	0	2°		
	_ L =	d 			
	I S	en ß			
		hed displacemer			
L L		gth of the closing			
	ß=dev	viation (check lim	its)		

Couplings applied on vacuum lines or with vacuum risk require an internal band unless gaps between pipes can be avoided. Please consult us in this situation.

39

	AR	POL FIX-U						
		Outside Diam (mm)	eter Maxir	Maximum Difference X (mm) 1,0 1,5 2,5				
		63						
	(	75 a 60						
	X÷2	110 a 355						
_		355 a 600		3,0				
		Coupling Width (mm)	No Internal Band (mm)					
	YY	99 - 118	5	15				
		200	10	35				
		Outside Di (mm		er Maximum Misalignment				
		< 300	0	1%				
		<u>&gt;</u> 300	)	3 mm				
		Outside Dia (mm)		r Max. Angular Deflection *				
	63 a 60	00	2°					
		* Please consult for higher values						
SHISOH V			d					
CON		L = d Sen <b>ß</b>						
		$\mathbf{Q}$ . <b>d</b> = wished displacement						
		$\mathbf{L}$ = length of the closing pipe						
	/*L	<b>ß</b> = deviation (check limits)						

ARPOL FIX-U couplings are designed to stand axial stress of pipes, however the pipeline must be properly supported. Should you need more information, please consult us

Couplings applied on vacuum lines or with vacuum risk require an internal band unless gaps between pipes can be avoided. Please consult us in this situation.

## ARPOL FIX-L - FITTING INSTRUCTIONS

#### INFORMATION INCLUDED ON THE LABEL:

- ARPOL reference.
- Outside diameter of the pipes to be joined.
- Working Pressure (bar)
- Test Pressure = 1,5 x working pressure
- Torque value (N/m)

#### STEPS TO ADEQUATELY FIT ARPOL FIX-L COUPLING:

- 1. Clean pipe ends and eliminate any irregularity.
- 2. Mark both pipe ends symmetrically at a distance from the edge equivalent to half of the coupling width.
- 3. Slide the coupling over one pipe end.
- 4. Bring the other pipe end to a facing position. Make sure the alignment limits as well as angular deflection, etc., are respected and that both pipe ends are correctly held.
- 5. Place the coupling between the marks and check that the inner steel bridge is correctly placed under the lock.

#### 6. Tighten screws:

- DO NOT TURN THE COUPLING WHEN SCREWS ARE BEEING TIGHTENED
  - 6.1. Start the tightening of screws using a click wrench with a nozzle.
    - **2 screws lock:** tighten both screws by alternative short movements until you nearly reach the end, but **do not exceed the torque value**.
    - 3 screws lock: First tighten the central screw up to 10 mm.
       Then tighten exterior screws positioning them at the same level as the central screw.
       Keep tightening the three screws by alternative short movements until you nearly reach the end, but do not exceed the torque value.
  - 6.2. Finish the tightening with a dynamometric wrench with sound signal.
    - Adjust the wrench to the torque value printed on the coupling label. Keep tightening screws alternatively with the dynamometric wrench until you can hear the 'click sound' at the beginning of the tightening.
- 7. If necessary, you may hydraulically test the coupling up to 1,5 the working pressure (see label).

## ARPOL FIX- M - FITTING INSTRUCTIONS

#### INFORMATION INCLUDED ON THE LABEL:

- ARPOL reference.
- Outside diameter of the pipes to be joined.
- Working Pressure (bar)
- Test Pressure = 1,5 x working pressure
- Torque value (N/m)

#### STEPS TO ADEQUATELY FIT ARPOL FIX-M COUPLING:

- 1. Clean pipe ends and eliminate any irregularity.
- 2. Mark both pipe ends symmetrically at a distance from the edge equivalent to half of the coupling width.
- 3. Slide the coupling over one pipe end.
- 4. Bring the other pipe end to a facing position. Make sure the alignment limits as well as angular deflection, etc., are respected and that both pipe ends are correctly held.
- 5. Place the coupling between the marks and check that the inner steel bridge is correctly placed under the lock.

#### 6. Tighten screws:

- DO NOT TURN THE COUPLING WHEN SCREWS ARE BEEING TIGHTENED
  - 6.1. Start the tightening of screws using a click wrench with a nozzle.
    - 2 screws lock: tighten both screws by alternative short movements until you nearly reach the end, but do not exceed the torque value.
      - 3 screws lock: First tighten the central screw up to 10 mm.
        Then tighten exterior screws positioning them at the same level as the central screw.
        Keep tightening the three screws by alternative short movements until you nearly reach the end, but do not exceed the torque value.
  - 6.2. Finish the tightening with a dynamometric wrench with sound signal.
    - Adjust the wrench to the torque value printed on the coupling label. Keep tightening screws alternatively with the dynamometric wrench until you can hear the 'click sound' at the beginning of the tightening.

7. If necessary, you may hydraulically test the coupling up to 1,5 the working pressure (see label).

# ARPOL FIX- U - FITTING INSTRUCTIONS

#### **INFORMATION INCLUDED ON THE LABEL:**

- ARPOL reference.
- Outside diameter of the pipes to be joined.
- Working Pressure (bar)
- Test Pressure = 1,5 x working pressure
- Torque value (N/m)


#### STEPS TO ADEQUATELY FIT ARPOL FIX-U COUPLING:


- 1. Clean pipe ends and eliminate any irregularity.
- 2. Mark both pipe ends symmetrically at a distance from the edge equivalent to half of the coupling width.
- 3. Slide the coupling over one pipe end.
- 4. Bring the other pipe end to a facing position. Make sure the alignment limits as well as angular deflection, etc., are respected and that both pipe ends are correctly held.
- 5. Place the coupling between the marks and check that the inner steel bridge is correctly placed under the lock.

#### 6. Tighten screws:

- DO NOT TURN THE COUPLING WHEN SCREWS ARE BEEING TIGHTENED
  - 6.1. Start the tightening of screws using a click wrench with a nozzle.
    - 2 screws lock: tighten both screws by alternative short movements until you nearly reach the end, but do not exceed the torque value.
    - 3 screws lock: First tighten the central screw up to 10 mm.
       Then tighten exterior screws positioning them at the same level as the central screw.
       Keep tightening the three screws by alternative short movements until you nearly reach the end, but do not exceed the torque value.
  - 6.2. Finish the tightening with a dynamometric wrench with sound signal.
    - Adjust the wrench to **the torque value printed on the coupling label**. Keep tightening screws alternatively with the dynamometric wrench until you can hear the 'click sound' at the beginning of the tightening.
- 7. If necessary, you may hydraulically test the coupling up to 1,5 the working pressure (see label).

# ARPOLTRANS





**TECHNICAL SPECIFICATIONS:** 

- 1, 2 or 3 look casing
- Specially designed rubber gasket (various models)
- · Steps of up tc 38 mm between outside diameters
- · Working pressures up to 10 bar

Flexible couplings for connecting pipes with different outside diameter





# ARPOLTRANS











#### A R P O L - T R A N S Difference (mm) between outside diameters

	A R P O TRANS-5		A R P O TRANS-10			A R P O TRANS-20				A R P O TRANS-30						
O.D.	O.D.		s and a second s	3 cks	- N	2 cks	star and a star	3 cks		2 cks	loc	3 ks			loc	3 ks
mm	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.
47 to 159	please	consult	-	-	-	-	-	-	-	-	-	-	-	-	-	-
160 to 230	2	10	-	-	-	-	-	-	-	-	-	-	-	-	-	-
230 to 250	2	10	2	11	-	-	-	-	-	-	-	-	-	-	-	-
251 to 299	2	10	2	11	5	15	4	16	15	25	14	26	-	-	-	-
300 to 349	2	10	2	11	5	15	4	16	15	25	14	26	25	35	24	36
350 to 499	2	10	2	12	5	15	3	17	15	25	13	27	25	35	23	37
> 500	2	11	2	13	4	16	2	18	14	26	12	28	24	36	22	38



# **ARPOL TRANS** - Fitting instructions

All ARPOL couplings are supplied with the following basic fitting instructions on the label:

- *f* ARPOL reference which includes the tolerance. Should different O.D. be joined, please check admissible values.
- *f* Working Pressure (bar)
- f Test Pressure = **1,5** working pressure
- f Torque value (N/m)

# In order to enable the ARPOL coupling to work correctly it is very important to respect the torque value.

To fit the ARPOL trans couplings, we recommend following these steps:


- 1 *f* Clean pipe ends and eliminate any irregularity.
- 2 f Mark both pipe ends symmetrically at a distance from the edge equivalent to half of the coupling width.
- 3 *f* Confirm that the coupling orientation is the adequate: The thicker rubber end is place at the smaller diameter.
- 4 f Slide the coupling over one pipe end without opening the coupling.
- 5 *f* Bring the other pipe end to a facing position. Make sure the pipes are aligned concentrically and that both pipe ends are correctly supported.
- 6 *f* Place the coupling between the marks and confirm that the inner steel bridge is correctly placed under the lock.

#### 7 f Tighten screws:

When the coupling has more than one lock, it is important to confirm that all the locks are equally open, even if the different bolts in each lock are not identically tightened.

- 7.1. Start the tightening of screws using a click wrench with a nozzle.
  - **2 screws lock:** tighten both screws by alternative short movements until you nearly reach the end, but **do not exceed the torque value**.
  - 3 screws lock: First tighten the central screw up to 10 mm. Then tighten exterior screws positioning them at the same level as the central screw. Keep tightening the three screws by alternative short movements until you nearly reach the end, but do not exceed the torque value.
- 7.2. Finish the tightening with a dynamometric wrench with sound signal.
  - Adjust the wrench to the torque value printed on the coupling label. Keep tightening screws alternatively with the dynamometric wrench until you can hear the 'click sound' at the beginning of the tightening.
- 8 *f* If necessary, you may hydraulically test the coupling up to 1.5 the working pressure (see label).

# **ARPOL TRANS COUPLINGS:**



## THE DIFFERENCE IN O.D. MUST BE EQUALLY DISTRIBUTED

The locks absorb <u>part</u> of the difference between O.D.s (A). Furthermore, couplings are fitted with a special rubber gasket that balances the <u>remaining</u> difference.



It is important that gaps between locks must be uniform.

ARPOL TRANS COUPLINGS ARE NOT DESIGNED TO SUPPORT THE PIPE OR TO PREVENT AXIAL MOVEMENTS. THEREFORE, THE PIPE MUST BE PROPERLY SUPPORTED AND ANCHORED.



P. Boonen & Co n.v. werd opgericht in 1987.

ONZE DOELSTELLING:

Fabricatie van geconfectioneerde rubberstukken en algemene rubberstukken Ontwerp en verkoop van flexibele leidingen en compensatoren Fabricatie en plaatsing van inkommatten en antislipmatten, voornamelijk in rubber

P. Boonen zorgt voor een permanente kwaliteitsverbetering en klantvriendelijke service. Ook wordt er efficiënt ingespeeld op de vragen van de klant. Advies, research en technische bijstand leiden tot een vlotte samenwerking bij het ontwikkelen van nieuwe producten en het verbeteren van bestaande producten.



s.a. P. Boonen & Cy a été fondé en 1987.

NOTRE OBJECTIF:

Fabrication de pièces moulées et pièces manufacturées en caoutchouc Etude et réalisation de tuyaux flexibles et compensateurs Fabrication et placement de tapis d'entrées et recouvrements de sol anti-dérapants en cautchouc

P. Boonen & Cy s'efforcent d'améliorer en permanence la qualité et le service aux clients. La recherche, les recommandations et l'assistance technique aident à réaliser une bonne collaboration pour le développement et la mise au point de nouveaux produits.

Industrieterrein "Krekelenberg" - Tunnelweg 14 2845 Niel - Belgium Tel. 32 (0)3.844.25.29 - Fax. 32 (0)3.844.31.40 info@boonenp.be - www.boonenp.be